

SHOW/BATTLE FOGGER HEATER BLOCK

PARTS LIST		
ITEM	PART NUMBER	DESCRIPTION
1	CXP-1258	LID COVER
2	CXP-2483	INSULATION KIT
3	CXP-4239	ANTI WARP PLATE
4	CLF-4402	RAPID CHANGE REPLACEMENT
5	CXP-1255	RAPID BLOCK BASE PLATE
6	CXP-1256	BLOCK BASE COVER
7	CLF-1257	#12X2" SUPPORT SCREW
8	CXP-1259	3/4" ALUMINUM PLATE
9	CLF-4402	6"X6" RAPID CHANGE REPLACEMENT (LARGE)
10	CXP-4231	1/4" ALUMINUM TOP PLATE
11	CXP-2227	THERMO DISC
12	CXP-1096	THERMOCOUPLE WIRE
13	CXP-4237	#8/32 X 1/2" SCREW
14	CXP-1268	3/8" STANDARD WASHER (BOTTOM)
15	CXP-1269	5/16" STANDARD WASHER (TOP)
16	CXP-1264	1250W ELEMENT
17	CXP-1267	COPPER SHIM
18	CLF-4402	5"X 6" QUICK CHANGE WEAR PLATE (SMALL)
19	CLF-4402	5/16" LOCK WASHER
20	CLF-4402	5/16" HEX NUT

REV-A

